

Port Bolivar: North Ferry Channel













HYDROGRAPHIC S

U.S. ARMY ENGINEER DIS

CORPS OF ENGINEER

GALVESTON, TEXAS

Channel Features – – Channel Center Line

— Channel Toe —— Channel Station Lines

← Channel Dimensions

Aids to Navigation

HOUSTON

PORT BOLIVAR

TEXAS CITY

1. Horizontal coordinates are referenced to texas state plane coordinate system, south central zone nad83 us survey feet.

2. Elevations are referenced to mean lower low tide (MLLW) datum. 4. The information depicted on this survey map represents the results of surveys made on the dates indicated and can only be considered as indicating the general conditions existing at that time. These conditions are subject to rapid change due to shoaling events. A prudent mariner should not rely exclusively on the information provided here. Required by 33 cfr 209.325

5. For the most up to date information please check our website at: http://www.swg.usace.army.mil/Missions/Navigation/HydrographicSurveys/

Service Layer Credits: World Topographic Map: Texas Parks & Wildlife, Esri, HERE, Garmin, INCREMENT P, USGS, METI/NASA, EPA, USDA World_Imagery: Maxar, Microsoft World_Imagery: Maxar World Ocean Base: Esri, GEBCO, Garmin, NaturalVue

Additional Combined Survey Dates and Stationing: COMB_SURV_INFO_HERE

Coordinate System: NAD 1983 StatePlane Texas South Central FIPS 4204 Feet Projection: Lambert Conformal Conic Dredging Reach Extent Hydrographic Survey Extent